

















## **INSTALLATION STAGES**

Wipe all parts with a damp cloth.

- 1) Iristall the drawer rails by layirig them ori a flat surface ori the right arid left sides.
- z) Sew the upper part with the uricoated part or the grourid.
- 3-4)Sew the left arid right sides iri the same way arid fix them with the cabiriet screwl.
- 5) Fix the lower part.
- 6) Form the cabinet by fixing it on the fixed shelf1.
- 7) by laying it on the clean floor,

arıd ırısert the mırııfıxes as showrı ırı the figure.

- 8) Put the miriifix, dowel arid miriifix equivalerits iri the places showri by layirig the drawer ori the right arid left sides.
- 9) Build the drawer case arid irisert it by pulling the backrest. Iristall the drawer slides.

Reverse the module arid fix the square feet to the places showri with 4xz5 screws. Fix the backrest with studs.

- Attach the caps to the places shown. Firially, place mobile shelves.
- 1z) Stick the white adhesive plugs ori the cabiriet screws..